




Using a Custom Food Code

- 1 Press and hold **RECALL**  until the scale display blinks "C" (about 3 seconds), indicating you are in Custom Mode.
To exit this mode, press and hold **RECALL** for about 3 seconds.
- 2 Enter your previously-saved custom 3-digit food code.
- 3 Use the scale as you normally would.

Enter your Custom Food Codes here

Press and hold **RECALL** for about 3 seconds until scale beeps; then enter a Custom Food Code

CODE	VEGETABLE	CODE	LEGUME	CODE	GRAIN	CODE	DAIRY & EGG

CODE	FRUIT	CODE	MEAT	CODE	LIQUID	CODE	SNACKS/OTHER

Need more space? Download a PDF copy of this form at www.MackieScientific.com